

Safety instructions

for AC built-in fans

The device type, date of manufacture (calendar week/model year) and the conformity sign are located on the type plate on the fan.

For questions about the fan, please provide the entire content of the type plate.

Revised: 2011-03-18
Version 3.1

CONTENTS

1. SAFETY REGULATIONS AND NOTES

1.1 Hazard levels of warnings	1
1.2 Staff qualification	1
1.3 Basic safety rules	1
1.4 Electrical voltage and current	1
1.5 Safety and protective functions	1
1.6 Electromagnetic radiation	1
1.7 Mechanical movement	2
1.8 Emissions	2
1.9 Hot surface	2
1.10 Transport	2
1.11 Storage	2
1.12 Disposal	2

2. PROPER USE 3

3. CONNECTION AND START-UP 3

3.1 Connecting the mechanical system	3
3.2 Connecting the electrical system	3
3.3 Checking the connections	4
3.4 Switching on the device	4
3.5 Switching off the device	4

4. MAINTENANCE, MALFUNCTIONS, POSSIBLE CAUSES AND REMEDIES 5

4.1 Safety examination	5
------------------------	---

1. SAFETY REGULATIONS AND NOTES

Please read these operating instructions carefully before starting to work with the device. Observe the following warnings to prevent malfunctions or physical damage to both property and people.

These operating instructions are to be regarded as part of this device.

If the device is sold or transferred, the operating instructions must accompany it.

These operating instructions may be duplicated and forwarded for information about potential dangers and their prevention.

1.1 Hazard levels of warnings

These operating instructions use the following hazard levels to indicate potentially hazardous situations and important safety regulations:



DANGER

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury. Compliance with the measures is mandatory.

WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury. Exercise extreme caution while working.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury or property damage.

NOTE

A potentially harmful situation can occur and, if not avoided, can lead to property damage.

1.2 Staff qualification

Only specialised electrical personnel may install the device, perform the test run and work on the electrical system.

Only trained and authorised specialist personnel are permitted to transport, unpack, assemble, operate or maintain the device, or to use it in any other manner.

1.3 Basic safety rules

Any safety hazards stemming from the device must be re-evaluated once it is installed in the end device.

Observe the following when working on the unit:

→ Do not make any modifications, additions or conversions to the device without the approval of ebm-papst.

1.4 Electrical voltage and current

Check the electrical equipment of the device at regular intervals.

Remove loose connections and defective cables immediately.



DANGER

Electrical load on the device

Electric shock

→ Stand on a rubber mat if you are working on an electrically loaded device.

WARNING

Terminals and connections have voltage even in a unit that is shut off

Electric shock

→ Wait five minutes after disconnecting the voltage at all poles before touching the unit.

CAUTION

The motor restarts automatically when operating voltage is applied, e.g. after a power failure.

Danger of injury

- Keep out of the danger zone of the device.
- When working on the device, switch off the mains supply voltage and secure the latter from being switched on again.
- Wait until the device stops.
- If thermal overload protectors are led through, insert these into the control circuit so that the cooled off motor does not switch on independently after a fault.

1.5 Safety and protective functions



DANGER

Missing safety device and non-functioning protective features

If there is no safety device, you could be seriously injured, for example by reaching into the running device with your hands.

- Operate the device only with a fixed guard and guard grille. The guard must withstand the kinetic energy of a fan blade.
- The device is a built-in component that has no function on its own. As the operator, you are responsible for ensuring that the device is adequately secured.
- Shut down the device immediately if you detect a missing or ineffective protective feature.

1.6 Electromagnetic radiation

Interference from electromagnetic radiation possible, e.g. in conjunction with open and closed-loop control devices.

If unacceptable emission intensities occur when the fan is installed, suitable shielding measures must be taken before the device is commissioned.

NOTE

Electrical or electromagnetic interferences after integrating the device in installations on the customer's side.

- Verify that the entire setup is EMC compliant.

1.7 Mechanical movement



DANGER

Rotating device

Body parts that come into contact with the rotor and impeller can be injured.

- Secure the unit to prevent contact. Before working on the installation/machine, wait until all parts have come to a standstill.

WARNING

Rotating device

Long hair, loose items of clothing and jewellery could become entangled and pulled into the device. You could be injured.

- Do not wear any loose clothing or jewellery while working on moving parts.
- Protect long hair with a hood.

1.8 Emission

WARNING

Depending on the installation and operating conditions, a sound pressure level greater than 70 dB(A) can arise.

Danger of noise-induced hearing loss

- Take appropriate technical safety measures.
- Safeguard the operating personnel with appropriate protection measures, e.g. ear protectors.

1.9 Hot surface



CAUTION

High temperature at the motor housing

Danger of burn injuries

- Ensure that sufficient protection against accidental contact is provided.

1.10 Transport

CAUTION

Transport of fan

- Transport the fan in its original packaging only.
- Secure the fan so that it does not slip, for example using a lashing strap.

1.11 Storage

Store the device in a dry and weatherproof manner in the original packing in a clean environment.

Protect the device from environmental impacts and dirt until the final installation.

We recommend storing the device for a maximum of one year.

Maintain the storage temperature.

1.12 Disposal

When disposing of the device, please comply with all relevant requirements and regulations applicable in your country.

2. PROPER USE

The device is exclusively designed as a built-in device for moving air according to its technical data.

Any other or secondary use is deemed improper and constitutes a misuse of the device.

Installations on the customer's side must meet the mechanical, thermal and service life-related stresses that can occur.

Proper use also includes:

- Using the device only in power systems that are earthed at the neutral. (Applicable only to three-phase devices)
- Moving air with a density of 1.2 kg/m³.
- Using the device in accordance with the permitted ambient temperature.
- Operating the device with all protective features.
- Observing the safety instructions.

Improper use

In particular, the following uses of the fan are prohibited and can lead to dangerous situations:

- Moving air that contains abrasive particles.
- Moving highly corrosive air, e.g. salt spray mist. Exceptions are devices that are intended for salt spray mist and protected accordingly.
- Moving air that contains dust pollution, e.g. suctioning off saw shavings.
- Using the fan to move flammable gases/particles.
- Operating the fan in the vicinity of flammable materials or components.
- Operating the fan in an explosive atmosphere.
- Using the fan as a safety component or for taking on safety-related functions.
- In addition, all application options that are not listed under proper use.

If you have specific questions, contact ebm-papst for support.

Electromagnetic compatibility



If several fans are switched in parallel on the mains side so that the line current of the arrangement is in the range of 16 - 75 A, then this arrangement conforms to IEC 61000-3-12 provided that the short-circuit power S_{sc} at the connection point of the customer system to the public power system is greater than or equal to 120 times the rated output of the arrangement.

It is the responsibility of the installation engineer or operator/owner of the device to ensure, if necessary after consultation with the network operator, that this device is only connected to a connection point with a S_{sc} value that is greater than or equal to 120 times the rated output of the arrangement.

3. CONNECTION AND START-UP

3.1 Connecting the mechanical system



CAUTION

Cutting and crushing hazard when removing the blower from the packaging

- Carefully lift the device out of the packaging; be sure to avoid any shock.
- Wear safety shoes and cut-resistant safety gloves.



CAUTION

Heavy load when taking out the device

Bodily injuries, e.g. back injuries, are possible.

- Two people should lift the device out of its packaging if it is heavier than 10 kg.

- Install the device according to your application.
- Use suitable fastening hardware for the installation.

3.2 Connecting the electrical system

The connection to the electrical system is made after the connection to the mechanical system.



DANGER

Electric voltage on the device

Electric shock

- Always install an earth wire. Check the protective earth.



DANGER

Incorrect insulation

Risk of fatal injury from electric shock

- Use only cables that meet the specified installation requirements for voltage, current, insulation material, load etc.



DANGER

Electrical load (>50 µC) between mains wire and protective earth connection after switching off the supply when switching multiple devices in parallel.

Electric shock, risk of injury

- Ensure that sufficient protection against accidental contact is provided.
- Before working on the electrical connection, the connections to the mains supply and PE must be shorted.

CAUTION

Electrical voltage

The fan is a built-in component and features no electrically isolating switch.

- Only connect the fan to circuits that can be switched off with an all-pole separating switch.
- When working on the motor, you must switch off the system/machine in which the motor is installed and secure it from being switched on again.

CAUTION

Electric shock

Electric voltage on the metal part

- Use the device only with the cable guard provided for this purpose (this instruction applies only to devices with terminal boxes).

Prerequisites

- Check whether the data on the type plate agree with the connection data.
- Before connecting the device, ensure that the mains supply voltage matches the fan voltage.
- Only use cables designed for current according to the type plate.

Residual current operated device



Only all-current-sensitive RCD protective devices (type A) are permissible. Like frequency inverters, RCD protective devices cannot provide personal safety while operating the device.

Voltage control



With open loop speed control using transformers or electronic voltage regulators (e.g. phase angle control), excessive current may occur. In addition, noises can occur with phase control, depending on the manner in which the device is installed.

Frequency inverter



Fit sinusoidal filters that work on all poles (live-live and live-earth) between the frequency inverter and the motor for operation with frequency inverters.

Motor protection

WARNING

Device without overheating protection

The device is delivered without any automatically functioning overheating protection. The device can become hot and burn.

- For the version without TOP, install an additional, suitable motor protection switch.

(Applicable only to devices without off-board TOPs)

CAUTION

Electrical voltage

The device is a built-in component and features no electrically isolating switch.

- Connect the device only to circuits that can be switched off using an all-pole disconnecting switch.
- When working on the device, you must switch off the system/machine in which the device is installed and secure it from being switched on again.

(Applicable only to devices with off-board TOPs)



The motors are equipped with thermal overload protectors to protect the devices.

Check to make sure that the thermal overload protector is correctly connected before each operation.

Failure to connect up the thermal overload protector correctly will invalidate your right to claim damage for any defects. (Applicable only to devices with off-board TOPs)

Connecting cables with terminals (applicable only to devices with terminal connection)

WARNING

Terminals and connections have voltage even in a unit that is shut off

Electric shock

- Wait five minutes after disconnecting the voltage at all poles

WARNING

Electric voltage on cable gland

Electric shock

- Do not use plastic terminal boxes with metal cable glands.

3.3 Checking the connections

- Ensure that the power is off.
- Secure it from being switched on again.
- Check the correct fit of the connecting cables.

3.4 Switching on the device

WARNING

Hot motor housing

Fire hazard

- Ensure that no combustible or flammable materials are located in the vicinity of the fan.

- Inspect the device for visible external damage and the proper function of the protective features before switching it on.
- Apply the nominal voltage to the voltage supply.

3.5 Switching off the device

- Separate the device from the supply voltage.

4. MAINTENANCE, MALFUNCTIONS, POSSIBLE CAUSES AND REMEDIES

Do not perform any repairs on your device. Return the fan to ebm-papst for repair or exchange.

WARNING

Terminals and connections have voltage even in a unit that is shut off

Electric shock

- Wait five minutes after disconnecting the voltage at all poles before touching the unit.

CAUTION

Electrical load on the capacitor after device is switched off

Electric shock, risk of injury

- Discharge the capacitor before working on the device.
(Applicable only to devices with capacitors)

CAUTION

The motor restarts automatically when operating voltage is applied, e.g. after a power failure.

Danger of injury

Keep out of the danger zone of the device.

- When working on the device, switch off the mains supply voltage and secure the latter from being switched on again.
- Wait until the device stops.
- If thermal overload protectors are led through, insert these into the control circuit so that the cooled off motor does not switch on independently after a fault.



If the device remains out of use for some time, e.g. when in storage, we recommend switching the device on for at least 2 hours to allow any condensate to evaporate and to move the bearings.

4.1 Safety examination

What has to be tested?	How to test?	Frequency
Protective casing against accidental contact	Visual inspection	At least every 6 months
Fan for damage	Visual inspection	At least every 6 months
Mounting of fan	Visual inspection	At least every 6 months
Mounting of connecting cables	Visual inspection	At least every 6 months
Insulation of the cables	Visual inspection	At least every 6 months

Malfunction/error	Possible cause	Possible remedy
Motor does not turn	<ul style="list-style-type: none"> Mechanical blockage – Mains supply voltage faulty – Faulty connection – Motor winding broken – Thermal overload protector responded (applicable only to devices with off-board TOPs) 	<ul style="list-style-type: none"> – Switch off, de-energise, and remove mechanical blockage – Check mains supply voltage, restore power supply – Correct the connection – Replace the device – Allow motor to cool off, locate and rectify cause of error, if necessary cancel switch-on inhibitor
Impeller running roughly	<ul style="list-style-type: none"> – Imbalance in rotating parts 	<ul style="list-style-type: none"> – Clean the device, if imbalance is still evident after cleaning, replace device
Overtemperature of motor	<ul style="list-style-type: none"> – Ambient temperature too high – Unacceptable operating point – Insufficient cooling 	<ul style="list-style-type: none"> – Lower ambient temperature if possible – Check operating point – Improve cooling



If you have any other problems, contact ebm-papst.